Setting Up a Front Row to go System

Here is the information that you require to set up your Front Row to go system:

- **This unit you receive is not charged. When you set it up in the classroom, place the speaker at the side of the classroom in the middle.**

- **The sound comes out of the speaker in a conical pattern and will cover the whole room from that location. One thing about your students, they will tell you if they can hear, can't hear, its too loud, etc.**

- **Plug both the tower speaker and the mic charger in to the wall, using the power cords provided. Make sure the tower is turned off at the bottom; it will charge overnight; in the morning, turn on the "on" switch at the bottom of the speaker column and volume at the top.**

- **With the body worn transmitter, you will be on Channel A. The charged transmitter should be good for up to 8 hours; the "to go" unit can be transported anywhere in the school or outside (track & field, gym, etc.) Every night, turn off the switch and place it in the mic charger to recharge.**

- **With a hand-held mic, you will be on Channel B. Every night, turn off the switch and place it in the mic charger to recharge.**

- **Put the rechargeable batteries (you can only use NiMH -- nickel metal hydride -- batteries; they do not hold a memory and have a recharge life of about 2 years, and then have to be replaced as they won't hold a charge after that) into the transmitter; make sure it is turned "off"; place the transmitter in the charger.**

- **A light (red) will come on showing you it is charging. In the morning, take it out of the charger (green), turn it on and it is ready to go. There is a mute setting on this unit, if the teacher prefers to have a private conversation. Get in the habit of using it rather than unplugging the headset, which will result in broken mic jacks, a costly repair.**

- **The headset plugs in to the top of the transmitter, with a new and very comfortable rubber band on the back. You are ready to go. Don't forget the auxillary input can be used for a laptop, cassette player, iPod, MP3, etc.**